





















LCD



B0: 1:1 0:0 (Bonding option)
 B1: 1:1 0:0 (Bonding option)
 ALARM: 1:4KHz 0:2KHz
 DU1,0: 00: 1/6 01: 5/1 10: 1/4 00: 1/3 (LCD duty)
 OSC1,0: 00: 32kCry 01: 32KRC 1X: 131KRC (續OSC)
 PCK: 1:4KHz 0:2KHz (Pump)
 RF: 1: CX->GND 0: CX->PB3
 RSTB: 1: Disable 0: Enable (Reset pull-up R)
 STKOVF: 1: Enable 0: disable



www.8051faq.com.cn TEL:0755-61361234